# **Exercise: Configuring a DHCP Server and Clients**

# **Objectives:**

In this exercise, you will set up a DHCP server and clients using Cisco Packet Tracer. You will configure a server to assign IP addresses dynamically to PCs and test network connectivity.

# Part 1: Building the Network

#### **Step 1: Add Network Devices**

- 1. Open Cisco Packet Tracer.
- 2. Add the following devices from the **Device-Type Selection Box**:
  - o **1 Server** → End Devices > Server
  - o **1 Switch** → *Network Devices* > *Switch* 2960
  - o **3 PCs** → End Devices > PC

#### **Step 2: Connect the Devices**

- 1. Use Copper Straight-Through Cables (Connections > Copper Straight-Through).
- 2. Connect:
  - Server (FastEthernet0) → Switch (anyFastEthernet )
  - Each PC (FastEthernet0) → Switch (any FastEthernet)

## Part 2: Configuring the DHCP Server

### **Step 3: Assign a Static IP to the Server**

- 1. Click the **Server**, go to the **Config** tab.
- 2. Select FastEthernet0 and configure:
  - o **IP Address:** 192.168.1.1
  - Subnet Mask: 255,255,255.0

### Step 4: Enable and Configure DHCP Service

- 1. Click the **Server**, go to the **Services** tab.
- 2. Select **DHCP** and **turn on the service**.
- 3. Set the following:
  - Start IP Address: 192.168.1.10

[Type here]

Subnet Mask: 255.255.255.0
Default Gateway: 192.168.1.1
Maximum Number of Users: 10

4. Click Save.

# Part 3: Configuring the PCs as DHCP Clients

#### Step 5: Set DHCP on Each PC

- 1. Click **PC0**, go to **Desktop > IP Configuration**.
- 2. Select **DHCP** and check if an **IP address is assigned** (e.g., 192.168.1.10).
- 3. Repeat for **PC1 and PC2**.

# **Part 4: Testing Network Connectivity**

#### **Step 6: Verify Connectivity with Ping**

- 1. Open **Command Prompt** on **PC0** (Desktop > Command Prompt).
- 2. Type: ping 192.168.1.11

(Replace with the IP of another PC or server.)

3. If successful, repeat on **PC1 and PC2** to test all connections.

#### Part 5: Turn off the DHCP Service

#### **Step 7: Turn off and Configure DHCP Service**

- 1. Click the **Server**, go to the **Services** tab.
- 2. Select **DHCP** and **turn off the service**.
- 3. Click Save.

### Step 8: Observe what IP address is assigned to Each PC

- 1. Click **PC0**, go to **Desktop > IP Configuration**.
- 2. Select **DHCP** and check what **IP** address is assigned
- 3. Repeat for **PC1 and PC2**
- 4. Think about why this IP address is assigned.

[Type here] 2